



Information Sheet

Catalog No. 0051380

OUTBOARD DESICCANT PACK





DESCRIPTION

A clear acrylic tube with replaceable indicating desiccant, designed to attach to the vent tube of vented RuggedCable™ stripped and tinned. Protects the device's cable and electronics from condensation of water vapor in high-humidity environments. The desiccant gradually turns from blue to pink as it becomes saturated with moisture.

Material Clear acrylic, nylon, HDPE membrane

(high density polyethylene)

Environmental rating Weatherproof, not designed for submersion Size 3.2 cm (1.25 in) O.D., 11.4 cm (4.5 in) long

Desiccant approx. 22 g silica gel, type 4

INSTALLATION

- 1. Snip off the knot at the bottom of the vent tube extension.
- 2. Attach the vent tube extension firmly to the cable vent tube. Cover at least a quarter-inch of the cable vent tube for a secure attachment.
- 3. Use the attached hook-and-loop strap to secure the desiccant to the cable, below the stripped wires, as shown in the lower photo at left.
- 4. Remove the red dust cap from the desiccant pack to allow air to reach the cable's vent tube.

GUIDELINES & PRECAUTIONS

- Desiccant will absorb moisture from the top down and for best results should be replaced before the entire volume has turned pink. Desiccant refill kits, Cat. No. 0029140, are available from In-Situ Inc. or your distributor.
- Protect new desiccant from moisture until ready to use. The supplied dust cap and the knot in the vent tube help to keep the desiccant dry.
- Be sure to remove the dust cap before deployment to allow air to reach the cable's vent tube.

1 800 446 7488