





## **5-inch Desiccant Pack**

Catalog No. 0087630

Replacement desiccant bags have one opaque side and one clear film side. Measuring 5 in x 4.75 in, they contain a combination of either clay or silica gel and blue indicating gel. Replace the desiccant pack when the blue beads become a pink color.

Place one or two bags inside the instrument housing, depending on your humidity levels, making sure not to disturb any of the wiring connections.

## Approximate size:

